

Rug Pad



We offer rug pads for rugs and runners to prevent slipping, allow extra comfort and extend the rug's life. We recommend rug pads for all wool rugs. Rug pads are used beneath your rug on smooth or hard floors (timber, parquet, laminate, tile, stone, marble, cork, and PVC floor coverings) and on heated floors. It can be used on carpets to prevent rugs from creeping.

Newly sealed floors must be completely dry and cured before laying any rug or rug pad. Measuring 1/8" (3 mm) in thickness, it provides additional walking comfort while satisfying the highest demands.

Imperial

5'7" x 7'10"

6'7" x 9'10"

8' x 10'

8'2" x 11'6"

9' x 12'

9'10" x 13'2"

10' x 14'

11'6" x 14'9"

2'7" x 13'2"

Metric

1.7 x 2.4 m

2 x 3 m

2.4 x 3 m

2.5 x 3.5 m

2.7 x 3.6 m

3 x 4 m

3 x 4.2 m

3.5 x 4.5 m

0.8 x 4 m

Notes

The rug pad will be 1" (2 1/2 cm) smaller than your rug on each side. Custom size available.

Fiber & construction

Fiber: **Felt and natural rubber**

Height: **1/8" (3 mm)**

Composition

100% recycled felt and natural rubber

Features and Benefits

Light adhesive on both sides

Enhances walking comfort

Prevents rugs from creeping

Grips through fiber

Free of folds

Easily to cut to size and lay

Odourless

Free of harmful substances

Improves the sound absorption

Residue free

Anchors rugs to both soft & hard floors

Can be used on heated floors

Underlay installation guide

1. Make sure the floor is vacuumed, clean and dry
2. Mark the position of the rug
3. Lay the underlay 1" (2 1/2 cm) inside the marks
4. Place the rug on top of the underlay
5. For oversized rugs, the underlay will be comprised of multiple pieces
6. Underlay can be trimmed using scissors if required